


MODEL 86-UD REPLACEMENT PARTS LIST



KEY NO	PART NO.	DESCRIPTION
1	A00-0602-052	WATER PAN ASSEMBLY
2	A00-1707-086	MOUNTING FRAME ASSEMBLY
3	000-1052-009	BRASS THUMB NUT 8-32 THD.
4	000-0803-040	HOLDING CLAMP
5	B48-0000-000	FLOAT VALVE
6	A00-1309-005	FLOAT FOR VALVE
7	A00-1708-002	VALVE SEAT
8	000-0693-033	RUBBER WASHER
9	000-1317-090	SCREW IN PLUG
10	A05-1721-042	MOTOR 24VAC.
11	A00-1128-005	SADDLE VALVE ASSEMBLY
12	A06-1722-019	DRUM ASSEMBLY= KEY#s 13,14,15
13	000-1722-021	LARGE OPEN DRUM END
14	000-1526-060	DRUM SHAFT
15	000-0692-029	DRUM CLIP / PACKAGED WITH NEW PAD
16	A04-1725-050	EVAPORATOR PAD / INCLUDES CLIPS
17	SK0-0055-001	HUMIDISTAT ASSEMBLY
18	000-0814-008	TRANSFORMER 24V, 10VA, 120V PRIMARY